

Model 400 Portable Floor Sentry

Model # SS-400-PFS

Product Specifications

BASE UNIT DIMENSIONS

22.5" Length, *Including Control Box*
 20" Width
 19.5" Height

ARM DIMENSIONS

6" Dia., 72" Long Fire-Retardant Flex Hose (10.5" Dia. Round Hood)

CABINET MATERIAL

16 ga. Carbon Steel

WEIGHT

Approx. 50 lbs. - 100 lbs.
Varies Depending on Filter Media Installed

AIR VOLUME

Variable Speed Control Standard on 115V
 700 CFM High, Down to 50 CFM Low
 On/Off Toggle Switch Standard on 220V

ELECTRICAL

115/1/60, 2.5 amps
 220/1/50, 1.5 amps
 8' grounded power cord with NEMA 5-15P Plug

SOUND LEVEL

Approx. 72 dba @ 3'

FILTRATION

Depending on the Application:

- HEPA [up to 99.97% efficient on particles 0.3 microns and larger]
- ASHRAE [up to 95% efficient on particles 0.5 microns and larger]
- ACTIVATED CARBON
- SPECIALTY-BLENDED FILTER MEDIA [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]

WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.
 PATENT #5,843,197



Dimensions are Approximate
 Shown with Optional Accessories



Product Features

- Variable Speed Controller *Included*
- Portable Handle *Included*
- Quiet Operation
- Reliable, Low Maintenance Operation
- Self Supportive, Flexible Arm
- Simple, Quick "No Tool" Filter Change
- Low Power Consumption
- Optional Magnehelic Gage
- Optional Hour Counter

The **Portable Floor Sentry fume extractor** is used as a respiratory safety control for a variety of industrial applications that require the capture and filtration of airborne contaminants and chemical fumes. This source-capture fume extractor features quiet operation, a powerful fan, a flame-retardant and self-supportive flex arm, and a variety of high-quality filtration media.

Typical applications for this unit include: welding fume control, chemical fume extraction, solvent and epoxy fume control, particulate extraction, powder filling, soldering, light grinding, clean room applications, and a variety of applications involving chemical fumes and dust.

Several filter media options are available for this unit and include: HEPA filtration [up to 99.97% efficient on particles 0.3 microns and larger, ASHRAE filtration [up to 95% efficient on particles 0.5 microns and larger], Activated Carbon, and specialty-blended filter media [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]. The Portable Floor Sentry allows multiple filter media to be housed inside the filter chamber for applications that emit both particulate and fume.

Other unit features include a variable speed controller, portability handle, 360-degree swivel arm, simple and quick "no-tool" filter change, and optional accessories including a magnehelic gauge, digital hour counter, and quick change pre-filter.

A smaller model [SS-300-PFS] and two larger models [SS-450-PFS & SS-500-BU-MP1] are also available.



1.800.799.4609
www.sentryair.com
sales@sentryair.com

