

Model 450 Dual Python Portable Floor Sentry — Multi-Operator Fume Extractor



Model # SS-450-PYTD

The **Model 450 Dual Python Fume Extractor** provides an engineering safety control for use in hard-to-reach applications with two extended flexible hoses suitable for multiple operators [i.e. tank welding]. The included 12 foot long, flame-retardant flex hoses feature a magnetic capture hood with handle that enables the operators to attach it to a surface to easily capture welding smoke, dust, or fumes. The unique dual hose design enables two nearby workers to use the same fume extraction system saving space and operating costs. This system provides up to 475 CFM per hose. This model can also be outfitted with dual 25 foot hoses.


Typical applications for this unit are *maintenance welding, light grinding applications, stainless steel tank welding, welding in confined spaces, fume extraction in elevated spaces [e.g. asbestos in ceiling and rafters], rapid location welding applications, stainless steel pipe welding, welding on metal beams, VOC removal, and particulate and fume removal.*

Other features of this system include quiet operation, heavy-duty casters for convenient mobility, and high efficiency filtration. Filtration media depends on the application, but typical media includes **HEPA filter** [up to 99.97% efficiency on particles 0.3 microns and larger], **ASHRAE filter** [up to 95% efficiency on particles 0.5 microns and larger], and **ULPA filter** [up to 99.9995% efficiency on particles 0.12 microns and larger] to capture particulate, and **activated carbon**, and **specialty-blended filter media** [i.e. acid gas, mercury, aldehyde, and ammonia] for chemical fume removal.

This **Model 450 Dual Python Portable Floor Sentry** combines energy-efficient technology and a unique design to ease fume extraction in hard-to-reach areas for two operators. Also available is a smaller model [SS-400-PYTD] and a model with a single extraction hose [SS-450-PYT].



Model 450 Dual Python Portable Floor Sentry



A welder utilizing the Python Portable Fume Extractor to help protect from welding fumes in a hard-to-reach area, fully taking advantage of the long flexible hose and magnetic hood. (SS-400-PYT shown above)

Product Features

- **Includes:** Variable speed controller (115V only), ON/OFF toggle switch (220V only), portability handle, (2) Magnetic welding hoods with handle, (2) 12' flex hose with 360-degree movement
- **Optional:** 25' flex hose and Magnehelic Gauge
- Quiet, reliable, and low maintenance operation
- Low power consumption
- Long filter life
- Simple, quick "no tool" filter change



21221 FM 529 Rd, Cypress, TX 77433
1.800.799.4609 • sales@sentryair.com
www.sentryair.com

Product Specifications



Dimensions are approximate

Base Unit Dimensions	Length: 22.5" (includes control box) Width: 20" Height: 19.5"
Arm Dimensions	6" Diameter (4" D optional) (2) 12' L fire-retardant flexible hose (25' L optional) 11" x 6.5" magnetic hood with handle
Cabinet Material	16 Ga. carbon steel
Weight (approximately)	62 - 112 lbs
Air Volume (approximately)	High: up to 475 CFM (per arm) Low: down to 50 CFM (per arm)
Electrical	115/1/60, 10.7 amps 220/1/50, 5.35 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level (at 3' from inlet)	Approx. 72 dba (High)
Main Filter Options	Depending on the Application: HEPA [up to 99.97% efficiency on particles 0.3 microns and larger] ASHRAE [up to 95% efficiency on particles 0.5 microns and larger] ULPA [up to 99.9995% efficiency on particles 0.12 microns and larger] Activated Carbon Specialty-Blended Filter Media [i.e. acid gas, mercury, aldehyde, and ammonia]
Limited Warranty	Limited two year warranty from date of shipment on defects due to materials or workmanship. Limited six-month warranty on fan/motor assembly
Patent #	5,843,197



21221 FM 529 Rd, Cypress, TX 77433
1.800.799.4609 • sales@sentryair.com
www.sentryair.com