

Model 450 Sky Sentry – Wall Mounted Fume Extractor



Model # SS-450-SKY

The **Model 450 Sky Sentry** is a wall mounted fume extractor that features a free hanging, self-supportive and flame-retardant flex arm that can easily be maneuvered by the operator to their desired location. In limited space environments, this unit frees up valuable benchtop and floor space while the flex arm provides a 62.5" swivel radius.

Typical applications for this system include: *welding fume extraction, brazing fume control, particulate extraction, removal of organic vapors, solvent and epoxy fumes, chemical fumes, light grinding, and various other industrial processes* where a wall-mounted fume extractor is needed.

This system utilizes a powerful fan to draw in most of the fumes and particulate into the filtration chamber before releasing the filtered air into the surrounding room. Depending on the application, several filter combinations can be utilized.

Typical filtration media include: **HEPA** (up to 99.97% efficiency on particles 0.3 microns and larger), **ASHRAE** (up to 95% efficiency on particles 0.5 microns and larger), **ULPA** (up to 99.9995% efficiency on particles 0.12 microns and larger), **Activated Carbon**, and **specialty-blended filtration media** [i.e. acid gas, mercury, aldehyde, and ammonia]. Multiple filter media can be housed inside the filter chamber for applications that emit both particulates and fumes.

Three smaller models [SS-200-SKY, SS-300-SKY, & SS-400-SKY] are also available. This system is also available with an outlet plenum.



Model 450 Sky Sentry



Model 450 Sky Sentry provides source capture fume extraction without taking up valuable benchtop space.

Product Features

- **Includes:** Variable speed controller with wired remote (115V only), ON/OFF toggle switch (220V only), wall mounting brackets, and self-supportive flexible arm with 62.5" swivel radius
- **Optional:** Magnehelic Gauge
- Quiet, reliable, and low maintenance operation
- Low power consumption
- Long filter life
- Simple, quick "no tool" filter change




21221 FM 529 Rd, Cypress, TX 77433
1.800.799.4609 • sales@sentryair.com
www.sentryair.com

Fume & Particulate Removal

Product Specifications

**MADE IN
THE USA**



*Dimensions are approximate
Shown with optional accessories*



21221 FM 529 Rd
Cypress, TX 77433
1.800.799.4609
sales@sentryair.com

www.sentryair.com

Base Unit Dimensions	Length: 21" Width: 20" (not including mounting brackets) Height: 19.5"
Arm Dimensions	4" diameter, 32" L fire-retardant flex arm, 15" L stainless steel ducting 7" diameter round hood
Cabinet Material	16 Ga. carbon steel
Weight (approximately)	62 - 112 lbs
Air Volume (approximately)	High: up to 950 CFM Low: down to 50 CFM
Electrical	115/1/60, 10.7 amps 220/1/50, 5.35 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level (at 3' from inlet)	Approx. 72 dba (High)
Main Filter Options	<i>Depending on the Application:</i> HEPA [up to 99.97% efficiency on particles 0.3 microns and larger] ASHRAE [up to 95% efficiency on particles 0.5 microns and larger] ULPA [up to 99.9995% efficiency on particles 0.12 microns and larger] Activated Carbon Specialty-Blended Filter Media [i.e. acid gas, mercury, aldehyde, and ammonia]
Warranty	Limited two-year warranty from date of shipment on defects due to materials or workmanship. Limited six month warranty on fan/motor assembly
Patent #	5,843,197