

## Mounted Fume Arm

### Model # SS-004-MFA

#### Product Specifications

##### ARM DIMENSIONS

45.75" Height, 20" Wide, 12.5" Deep

##### HOSE DIMENSIONS

4" Diameter

##### MATERIAL

Base: Carbon Steel

Hose: 4" Fire Retardant Flex

##### WEIGHT

Approximately 16 lbs.

##### WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.

All Specifications are approximate



#### Product Features

- Easily Transportable
- Reliable, Low Maintenance Operation
- Heavy-Duty Construction
- 4" Fire Retardant Flexible Hose

The SS-004-MFA mounted fume arm is an easily portable extraction arm that is lightweight and can quickly be adapted to a remote work area where a conventional fume extractor may not be practical. When connected to a Sentry Air Systems portable fan unit or shop exhaust, the mounted fume arm can be clamped to a table or used in other makeshift or temporary work areas. The mounted fume arm utilizes a fire retardant 4" diameter hose and is designed for soldering, brazing, TIG Welding or other light particulate/chemical fume removal. Connecting a multi-station 4" Mounted Fume Arm operation to a central exhaust or large filtration air handler is another excellent choice.



1.800.799.4609  
[www.sentryair.com](http://www.sentryair.com)  
[sales@sentryair.com](mailto:sales@sentryair.com)

