Model 200/225 Mini Fume Extractor

Model # SS-200/225-MFE

The Mini Fume Extractor extracts fumes and particulate in hard-to-reach areas. The system's small size, quiet operation, convenient mobility, and high efficiency filtration provides an excellent choice for several applications including: maintenance welding, brazing, soldering, light epoxy or solvent fume removal, chemical fumes, and particulate extraction. The convenient carrying handle and magnetic hood make this unit highly portable.

Filter options for this unit include: HEPA (up to 99.97% efficiency on particles 0.3 microns and larger), ASHRAE (up to 95% efficiency on particles 0.5 microns and larger), Activated Carbon, and specialty-blended filtration media (i.e. acid gas, mercury, aldehyde, and ammonia) are the most common options.

The Mini Fume Extractor provides an excellent choice for maintenance applications and for those requiring fume extraction in confined spaces. The included 43" long, fireretardant python hose is extremely flexible and easily maneuverable.

Larger models are also available [SS-300-PYT & SS-400-PYT].

Product Features

- Included: 43" length x 3" diameter fire-retardant flex hose and magnetic capture hood
- Optional: variable speed controller (115V only) and hour counter
- Highly portable and lightweight
- Reliable, low maintenance operation
- Quiet operation
- Simple, quick "no tool" filter change
- Long filter life
- Small footprint



21221 FM 529 Rd, Cypress, TX 77433 1.800.799.4609 • sales@sentryair.com

www.sentryair.com



Model 200/225 Mini Fume Extractor



Model 200/225 Mini Fume Extractor is similar to the Model 400 Python Portable Floor Sentry which provides hands-free fume extraction for hard to reach areas and applications.



Product Specifications



Dimensions are approximate.



21221 FM 529 Rd Cypress, TX 77433 1.800.799.4609 sales@sentryair.com

www.sentryair.com

	SINCE 1983
Base Unit Dimensions	Length: 10.5" (includes control box) Width: 8" Height: 12"
Arm Dimensions	3" diameter x 43" L 7" x 3.5" capture hood
Cabinet Material	16 ga. carbon steel
Weight	Approx. 15 lbs
Air Volume (approximately)	Pre-Filter + HEPA: 200: up to 80 CFM 225: up to 91 CFM
Electrical	200: 115/1/60, 0.3 amps 220/1/50, 0.2 amps 225: 115/1/60, 0.46 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level (High at 3' from inlet)	200: Approx. 56 dba 225: Approx. 64 dba
	Depending on the Application: 200 - Chemical: Activated Carbon Specialty-Blended Filter Media [i.e. acid gas, mercury, aldehyde, and ammonia]
Main Filter Options	225 - Particulate: HEPA [up to 99.97% efficiency on particles 0.3 microns and larger] ASHRAE [up to 95% efficiency on particles 0.5 microns and larger] ULPA [up to 99.9995% efficiency on particles 0.12 microns and larger]
US Patent	#5,843,197

