

Model 200 Mounted Sentry Single

Model # SS-200-MSS

Product Specifications

BASE UNIT DIMENSIONS

10.5" Length
 10" Width, *Including Mounting Brackets*
 10.5" Height

ARM DIMENSIONS

3" or 4" Diameter x 28" Long (5" or 6.5" Dia. Round Hood)

CABINET MATERIAL

16 ga. Carbon Steel

WEIGHT

Approx. 10 lbs.

AIR VOLUME

Up to 100 CFM. *Varies with filter media.*

ELECTRICAL

115/1/60, Approx. 0.3 Amps
 220/1/50, Approx. 0.2 Amps
 8' grounded power cord with NEMA 5-15P Plug

SOUND LEVEL

Approx. 58 dba @ 2' from inlet

FILTRATION

Depending on the Application:

- HEPA [up to 99.97% efficient on particles 0.3 microns and larger]
- ASHRAE [up to 95% efficient on particles 0.5 microns and larger]
- ACTIVATED CARBON
- SPECIALTY-BLENDED FILTER MEDIA [i.e. Acid Gas, Mercury, Aldehyde, Ammonia]

WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.
 PATENT #5,843,197



3" or 4" Diameter x 28" L Flex Arm

Dimensions are Approximate

Product Features

- Self-Supportive 28" L Flex Arm *Included*
- Quiet Operation
- Long Filter Life
- Mounting Brackets *Included*
- Simple, Quick "No Tool" Filter Change
- Optional Variable Speed Controller (115V only)
- Highly Portable and Lightweight
- Reliable, Low Maintenance Operation
- Optional Hour Counter

The **Mounted Sentry Single** fume extractor is an excellent choice for small or limited workspace environments where clean air is desired. The unit features a self-supportive flex arm that provides source capture of airborne contaminants, while mounting options can free up much needed workspace. Mounting configurations include bench-mounting, under-the table mounting, and shelf or wall mounting.

Typical applications for this unit include soldering, chemical fumes, solvent and epoxy fumes, laser fumes, light grinding, and many other procedures that involve the emission of particulate and fume.

High-quality filter media for this unit is customized depending on the application being performed, but typically includes HEPA filters [up to 99.97% efficient on particles 0.3 microns and larger], ASHRAE filters [up to 95% efficient on particles 0.5 microns and larger], Activated Carbon, and specialty-blended filtration media [i.e. Acid Gas, Mercury, Aldehyde, Ammonia].

The **Mounted Single Sentry** provides an effective, quiet and economical solution to many fume extraction needs.

A larger model [SS-300-MSS] and a dual-arm unit [SS-200-MSD] are also available.



1.800.799.4609
www.sentryair.com
sales@sentryair.com

