

# Model 200 Solder Pot Sentry

## Model # SS-200-PS

### Product Specifications

#### BASE UNIT DIMENSIONS

10.5" Length, Including Control Box  
8" Width  
10.75" Height

#### HEIGHT STAND DIMENSIONS

8.5" L x 9.5" W x Adjustable up to 8.75" H

#### CABINET MATERIAL

16 ga. Carbon Steel with Polyester Epoxy Coating on Surface

#### WEIGHT

Approx. 17 lbs.

#### AIR VOLUME

Up to 100 CFM. *Varies with Filter Media.*

#### ELECTRICAL

115/1/60, Approx. 0.3 Amps  
220/1/50, Approx. 0.2 amps  
8' grounded power cord  
with NEMA 5-15P Plug

#### SOUND LEVEL

Approx. 58 DBA at 3'

#### FILTRATION OPTIONS

**HEPA FILTRATION-**  
Up to 99.97% efficient on particles 0.3 microns and larger.

**ASHRAE FILTRATION-**  
Up to 95% efficient on particles 0.5 microns and larger.

*These filters are composed of flame-retardant materials.*

#### WARRANTY

Limited two-year warranty from date of shipment on defects due to materials or workmanship.

PATENT #5,843,197



Dimensions are Approximate

## Product Features

- Height Stand Included
- Quiet Operation
- Sturdy Construction
- Highly Portable and Lightweight
- Long Filter Life
- Optional Variable Speed Control (115V only)
- Reliable, Low Maintenance Operation
- Simple, Quick "No Tool" Filter Change
- Optional Velometer

The **Model 200 Solder Pot Sentry** is designed to capture and purify airborne smoke and particulate emitted during slightly elevated soldering applications, such as solder pot use. This benchtop unit features a small footprint, energy-efficiency, and quiet operation. The included height stand is adjustable up to 8.75".

This recirculating fume extraction system utilizes high-quality filtration media that typically consists of either HEPA or ASHRAE filtration. Sentry Air's HEPA filters are up to 99.97% efficient on particles 0.3 microns and larger, while ASHRAE filters are up to 95% efficient on particles 0.5 microns and larger. Both filters are uniquely constructed from flame-retardant materials.

The **Model 200 Solder Pot Sentry** offers a simple and efficient benchtop solution to solder pot fume control and other slightly elevated soldering applications.



1.800.799.4609  
www.sentryair.com  
sales@sentryair.com

