

Model 2000 Ambient Mist Collector

MADE IN
THE USA



SINCE 1983

Model # SS-2000-MIST

The **Model 2000 Ambient Mist Collector** captures and collects excess airborne mist commonly found in machining and tooling shops. The filtration system pulls air through **four mesh pre-filters** into a **main filter bag** both specially-designed to handle mist and other wet environments. Collected mist drains into a plug at the base of the unit for repurposing and recycling if applicable.

Typical applications include *general shop mist collection, open CNC lathes and waterjet machines that produce ambient mist, and other applications that produce oil mist, water mist or coolant mist.*

The **Model 2000 Ambient Mist Collector** commonly hangs from a ceiling but alternatively can be installed by mounting to our Fume Extractor Stand, placing the unit on a cart or table, or mounting to a wall shelf. Depending on the size of the work area, your facility may need multiple systems to be installed to better cleanse the air and create optimal airflow patterns. The **Model 2000 Ambient Mist Collector** provides a mist control solution for environments where direct-mounting a mist collection system is not available or feasible.

This unit has been stringently tested and evaluated by a third-party to verify that all internal components are able to withstand a moist environment.



Model 2000 Ambient Mist Collector



Model 2000 Ambient Mist Collector collects more than just oil mist, this system can be used for waterjet machines.

Product Features

- Long filter life
- Four-way adjustable gate
- Reliable, low maintenance operation
- Low power consumption
- Quiet operation
- Simple, quick “no tool” filter change




Model 2000 Ambient Mist Collector provides additional support for mist collection in CNC machine shops.



21221 FM 529 Rd, Cypress, TX 77433
1.800.799.4609 • sales@sentryair.com

www.sentryair.com

Product Specifications



Dimensions are approximate

Base Unit Dimensions	Length: 45" Width: 24" Height: 24"
Outlet Configuration	Four-way adjustable grate
Cabinet Material	16 Ga. carbon steel with polyester powder coating
Weight (approximately)	124 lbs
Air Volume (approximately)	Up to 2,000 CFM (high)
Electrical	208-230/1/60, 5.6 amps 8' grounded power cord with pigtail
Sound Level (High at 6' from inlet)	Approx. 70 dba
Filtration	(4) Cleanable Mesh Pre-Filter (1) Oil Mist Bag Filter
Warranty	Limited two-year warranty from date of shipment on defects due to materials or workmanship.



21221 FM 529 Rd
Cypress, TX 77433
1.800.799.4609
sales@sentryair.com

www.sentryair.com