## Model 300 Portable Floor Sentry Double Fume Extractor



Model # SS-300-FSD

The **Model 300 Floor Sentry Double** is uniquely designed to provide portable fume extraction to two operators simultaneously. Two flame-retardant, self-supportive flex arms provide equal suction at both inlets, which directs contaminants into the patented filtration system.

Typical applications for this unit include soldering, welding, chemical fumes, light grinding, solvent and epoxy fume control, dust, pharmaceutical powders and many other procedures that involve the emission particulate and fume.

Standard filtration options for this system include: **HEPA** (up to 99.97% efficient on particles 0.3 microns and larger), **ASHRAE** (up to 95% efficient on particles 0.5 microns and larger), **Activated Carbon**, and **specialty-blended filter media** (i.e. acid gas, mercury, aldehyde, and ammonia). The **Floor Sentry Double** allows multiple filter media to be housed inside the filter chamber for applications that emit both particulates and fumes.

This unit features heavy-duty casters for easy mobility, flex arms that are capable of 360 degree rotation, and an infinitely-adjustable variable speed controller. Endcaps to plug inlet holes are available when use of only one arm is desired. Other optional features include a digital hour counter and quick change pre-filter.

The **Floor Sentry Double** can provide an energy efficient and economical solution for many commercial, medical, laboratory, pharmaceutical and industrial applications. *This unit is also available with a single arm* [SS-300-PFS], in a mounted configuration [SS-300-MSD], and in larger [SS-400-FSD & SS-450-FSD] and smaller models [SS-200-FSD].

## **Product Features**

- Includes: Portability handle, variable speed controller (115V only), and ON/OFF Switch (220V only)
- Optional: Magnehelic Gauge and hour counter
- · Quiet operation
- Reliable, low maintenance operation
- Low power consumption
- · Simple, quick "no tool" filter change
- · Long filter life



Model 300 Floor Sentry Double



Two operators using the Floor Sentry Double unit to extract soldering fumes simutaneously.









Dimensions are approximate



21221 FM 529 Rd Cypress, TX 77433 1.800.799.4609 sales@sentryair.com

www.sentryair.com

SINCE 1903	
Base Unit Dimensions	Length: 15.5" (Including Control Box) Width: 13" Height: 16.5"
Arm Dimensions	<ul><li>(2) 4" or 5" diameter x</li><li>68" long fire-retardant flex arm</li><li>7" round capture hood</li></ul>
Cabinet Material	16 ga. carbon steel with polyester epoxy coating
Weight (approximately)	40 - 55 lbs
Air Volume (approximately)	Up to 175 CFM per arm
Electrical	115/1/60, 2 amps 220/1/50, 0.75 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level	Approx. 61 to 66 dba
Main Filter Options	Depending on the Application:  HEPA [up to 99.97% efficiency on particles 0.3 microns and larger]  ASHRAE [up to 95% efficiency on particles 0.5 microns and larger]  Activated Carbon  Specialty-Blended Filter Media [i.e. acid gas, mercury, aldehyde, and ammonia]
Limited Warranty	Limited two-year warranty from date of shipment on defects due to materials or workmanship.