Model 700 Free-Hanging Air Cleaner

Model # SS-700-FH

The Model 700 Free-Hanging Air Cleaner offers mid-size commercial grade air filtration with a quad-filter chamber. This system is highly effective for removing renegade and ambient pollutants without the need for external ducting, or make-up air.

This compact unit can be mounted in multiple configurations. The system can be affixed to a desired ceiling location, either flush mount and in a free-hanging mount. Both options take up zero floor and benchtop space. Also these systems can use our Fume Extractor Stand [SS-091-FES] which takes up minimal floor space and is ideal for environments with high ceilings.

Typical applications include laboratories, solvent fume control, pharmacy pill dust, secondary clean room scrubber, ambient shop fume control, and light grinding. It is also effective for general air cleaning in environments such as restaurants, event venues, game halls, community buildings, offices, cafeterias, cigar and tobacco lounges, sports facilities, and other commercial arenas.

The quad-stage filtration system uses pre-filters and post-filters with two full-size filters in the main filter chamber. Pre-filters and post-filters offer a MERV 7 rating with up to 70% efficiency on particles 3 microns and larger. Main filter options include HEPA filters [up to 99.97% efficiency for particles 0.3 microns and larger], ASHRAE filters [up to 95% efficiency for particles 0.5 microns and larger], and refillable Activated Carbon filters or specialty blended filter media (acid gas, ammonia, aldehyde, and mercury). For applications that have both particulates and chemical fumes, this system can utilize dual filtration with a HEPA filter or ASHRAE filter with an activated carbon filter or specialty blended filter media.

In addition to the Model 700, Sentry Air offers the Model 2000 Free Hanging Ambient Air Cleaner for industrial-strength filtration.

Product Features

- Quad filtration chamber: pre-filter, two main filters, and post-filter
- Main filter choices: HEPA, ASHRAE, Activated Carbon and specialty blended filter media
- Easy access to filters
- Adjustable grill •
- · Reliable, low maintenance operation
- Low power consumption
- Simple, quick "no tool" filter change
- Long filter life
- Sturdy construction



21221 FM 529 Rd, Cypress, TX 77433 1.800.799.4609 • sales@sentryair.com



Model 700 Free-Hanging Air Cleaner



Model 700 shown on Fume Extractor Stand (above) and ceiling mounted (below).





www.sentryair.com

Product Specifications





Dimensions are approximate



21221 FM 529 Rd Cypress, TX 77433 1.800.799.4609 sales@sentryair.com

www.sentryair.com

	Since 1983
Base Unit Dimensions	Width: 32.625" Depth: 24.75" Height: 14.5"
Outlet Configuration	Four-way adjustable grill
Cabinet Material	16 Ga. powder coated carbon steel
Weight (approximately)	132 - 160 lbs
Air Volume (approximately)	Up to 770 CFM
Electrical	115/1/60, 4.9 amps 8' grounded power cord with NEMA 5-15P plug
Sound Level (High at 3' from inlet)	Approx. 71 dba
Filtration	MERV 7 Pre-filter and Post Filter (up to 70% ef- ficiency on particles down to 3 microns) HEPA Filter (up to 99.97% efficiency on particles down to 0.3 microns) ASHRAE Filter (up to 95% efficiency on particles down to 0.5 microns) Activated Carbon Specialty-Blended Filter Media [i.e. acid gas, mercury, aldehyde, and ammonia]
Warranty	Limited two-year warranty from date of shipment on defects due to materials or workmanship.
US Patent	#5,843,197